

HIGH TEMPERATURE DISH MACHINE

Deliming/Descaling Procedures

Cleaning Procedures

1. Turn off detergent dispensing equipment
2. Turn off dish machine, heater/booster heater
3. Empty water from the wash tank(s)
4. Remove, clean, and replace screens, scrap trays, etc.
5. Inspect lower and upper wash arms, clean if needed
6. Inspect rinse jets, remove and open tips if needed
7. Refill machine with fresh water
8. Add Deliming/Descaling Solution into machine wash tank
9. Turn machine on; **KEEP HEATING ELEMENTS OFF**
10. Cycle dish machine until it is free of lime scale
11. Inspect wash arms, rinse jets, etc.
12. If needed, add more Deliming/Descaling Solution and continue to cycle machine

After Machine is Clean and Free of Lime Scale

13. Turn machine off
14. Empty water from wash tank
15. Refill machine with fresh water
16. Turn on machine, heater/booster heater and detergent dispenser

Machine is now READY for use

