

LOW TEMPERATURE DISH MACHINE

Deliming/Descaling Procedures

Cleaning Procedures

1. Turn off chemical feed switch if available or remove chemical feed lines from containers
2. Drain and empty any water from machine
3. Inspect arms, clean if needed
4. Remove, clean, and replace drain screen
5. Turn machine on and fill
6. Run one cycle to remove any trace amounts of chlorine sanitizer
7. Refill machine
8. Add Deliming/Descaling Solution directly to the wash tank or add to the drain port
9. Cycle machine
10. Inspect inside of machine/wash arms
11. Repeat cycle(s), adding delimer until machine is free of scale buildup



After Machine is Clean and Free of Lime Scale

12. Cycle machine one more time to rinse Delimer/Descaler from tank and pump
13. Drain machine
14. Fill machine with water
15. Turn chemical feed switch back or place feed tubes back into containers
16. Prime chemical feed pumps

Machine is now READY for use